

Assembly Instruction

ITEM N0.: 9602GY/NCH-1 Rocker Reclining Chair





Back Rest are stored at the bottom of chair, please take out **it for** assembly hardware for assembly.

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to spliting or cracking the wood.

Component list

| No | Drawing | Qty | Description |
|----|---------|-----|-------------|
| Α | | 1 | SEAT |
| В | | 1 | BACK REST |





Care Instruction for Polished microfiber Furniture: In order to maintain the original appearance of your polished microfiber Furniture, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage PU fabric.
- Vacuum or wipe with a soft cloth to remove dust.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.